

EXTRACTORS for dismantling PE pipes DN 25 - 50

05.400




Product description

- Extractors for dismantling PE pipes

Features

- Allows the extraction of PE pipes in service valves connection and fittings with POM tension ring, in order to relieve the pressure that the tension ring exerts on the PE pipe
- Consult our technical services for other dimension.



Fucoli Somepal
FUNDAÇÃO DE FERRO, S. A.



Visit our website at www.fucoli-somepal.pt

Head office: Estrada de Coselhas, 3000-125 Coimbra – Portugal | Tel.: (+351) 239 490100 | Fax: (+351) 239 490198

Branch office: Rua de Aveiro 50, 3050-420 Pampilhosa – Portugal | Tel.: (+351) 239 490100 | Fax: (+351) 231 949292 | comercial@fucoli-somepal.pt

EXTRACTORS
for dismantling PE pipes
DN 25 - 50

05.400



Extraction for
dismantling for PE pipe system

Component list

pos.	components	material	standard
1	Extractor	Steel	C75
2	Blind rivets	Stainless steel A2	EN 10088 - 1
3	Support of the extractor	Aluminium AW 2030	EN 573 - 3

Reference and dimensions

DN	Ø pipe ext. PE	code	n° uni.	L mm	D mm	H mm	Kg approx.
20	25	10720140	2	106	37	30	0.1
25	32	10720141	2	106	44	35	0.1
32	40	10720142	2	106	52	37	0.1
40	50	10720143	2	106	62	47	0.2
50	63	10720144	2	106	75	52	0.2



Fucoli Somepal
FUNDAÇÃO DE FERRO, S.A.

Visit our website at www.fucoli-somepal.pt

Head office: Estrada de Coselhas, 3000-125 Coimbra – Portugal | Tel.: (+351) 239 490100 | Fax: (+351) 239 490198

Branch office: Rua de Aveiro 50, 3050-420 Pampilhosa – Portugal | Tel.: (+351) 239 490100 | Fax: (+351) 231 949292 | comercial@fucoli-somepal.pt

